A


This document contains technology subject to the Export Administration Regulations (15 C.F.R. Parts 730-774). A prior authorization or license from the U.S. Department of Commerce, Bureau of Industry (and Security (BIS) is required prior to the export, re-export, release, or transfer of this document to a non-U.S. person whether in the United States or abroad.



MAG1440 - MOE RL Stock

MOE RL STOCK INSTALLATION INSTRUCTIONS


MARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY ENGAGED.



STEP 1: REMOVE EXISTING STOCK

Remove existing stock per armory guidelines.


Refer to US Army TM 9-1005-319-23&P Unit and Direct Support Maintenance Manual for assistance.



STEP 3: VERIFY INSTALL

Perform final inspection including function test per *US Army TM 9-1005-319-23&P* to verify correct installation. If you experience any issues during installation, please refer to the *RESOURCES* tab, located on the product page at *www.magpul.com*.


Always test fire your weapon before using it in an operational environment.



STEP 2: INSTALL MOE RL STOCK


DO NOT FORCE PARTS TOGETHER! Align the *Stock Body* with the *Carbine Receiver Extension* and gently slide together until the *stock* stops (approx 2-1/8"). Depress *Release Latch* with first hand (A). With other hand, grasp both ends of *Release Pin* and pull down firmly (B). Push *stock* forward to mount.

MOE® RL STOCK ADJUSTMENT INSTRUCTIONS



EXTEND/COLLAPSE STOCK

Fully depress the *Release Latch* (A) and pull the stock rearward to extend or push *stock* forward to collapse. Intermediate positions may be selected by partially depressing the *Release Latch* (A) and moving the *stock* back to the desired position.



REMOVING MOE RL STOCK

Depress Release Latch (A) with first hand. With other hand, grasp both ends of Release Pin and pull down firmly (B). Pull the Stock Body clear of the Carbine Receiver Extension.

092-0098-A